



SECTION

NOTES:

1. INSTALL TOP OF TUBE AT FINISH GRADE OF MULCH
2. ALL PVC THREADS TO HAVE TEFLON TAPE

