



NOTES:

1. EACH REMOTE CONTROL VALVE SHALL BE INSTALLED IN A SEPARATE VALVE BOX ACCORDING TO THE IRRIGATION SPECS AND BOXES SHALL BE CENTERED OVER VALVES.
2. MANIFOLDS SHOULD HAVE FEED SEPARATE FROM MAINLINE WITH GATE VALVE (AS SHOWN).
3. INSTALL ONE GATE VALVE AHEAD OF A GROUP OF REMOTE CONTROL VALVES IN A SEPARATE ROUND VALVE BOX.
4. INSTALL ONE GATE VALVE AHEAD OF A SINGLE RCV IN THE SAME RECTANGULAR VALVE BOX.
4. SET BOXES IN GROUND COVER/SHRUB AREA WHERE POSSIBLE AND SET BOXES PARALLEL TO EACH OTHER AND PERPENDICULAR TO EDGE OF HARDSCAPE.
5. IF QC VALVE IS FURTHER THAN 5 FEET FROM MANIFOLD, INSTALL ADDITIONAL GATE VALVE.