



NOTES:

1. FILTER AND VALVE MUST BE ACCESSIBLE FOR MAINTENANCE. VERIFY WITH UNIVERSITY'S REPRESENTATIVE.
2. MAINTAIN 3" OF CLEARANCE INSIDE ON EITHER SIDE OF VALVE BOX. UNION CAN BE LOCATED OUTSIDE OF BOX.
3. STANDARD SIZE VALVE BOXES MAY REQUIRE UPGRADE TO LARGER SIZE, SEE SPECS.
4. COMPACT SOIL AROUND VALVE BOX TO SAME DENSITY AS UNDISTURBED SOIL.